

Installation



- A Fit the dowels in the dowel holes in the cavity plate.
- ® One-by-one fit the **nozzles** into the **cavity plate**.



- (A) Check that all **nozzle** sealing faces are level within 0.02mm.
- ® Clip the wires to the cavity plate to prevent the wires from touching the manifold.