
# The importance of Gate Cooling

When designing a mould for a direct gated part that uses a Hot Runner System it is critical to consider effective cooling at the gate and in the Hot Runner System plates.

Inadequate gate cooling can result in poor gate vestige and/or extended cycle times. Part quality issues such as splay or bloom can also result from a poorly designed tool.

Insufficient cooling in the back plate or manifold housing plate can result in excessive heat transfer to the rest of the mould or machine platen, plate distortion or insufficient sealing forces within the Hot Runner System.





During the initial tool design process it is important to consider the following influential factors when considering gate cooling.

- Gate Insert design and material
- Distance of circuit from gate
- Thermal conductivity of insert
- No part line between gate and circuit
- Controllability




www.mastip.com


# The Importance of Gate Cooling

### **Gate Cooling**

Gate Cooling needs to be on a separate circuit to the mould plate.


| KEY |                           |
|-----|---------------------------|
|     | Water In Cooling Circuit  |
|     | Water Out Cooling Circuit |
|     | Manifold Plate            |
|     | Cavity Plate              |







## **Dimples**

Design dimples for maximum material thickness around gate








#### **Valve Gate Cooling Circuits**

Manifold plate circuit
Back plate circuit

Valve Gate cylinders require cooling on two sides of cylinders

| KEY             |
|-----------------|
| Cooling Circuit |
| Airway          |



#### **Successful Tooling Projects**

Proper tool design will result in efficient cycle times, good part quality and efficient transition of new tooling into full production.

Your Mastip Technology engineering team is available for consultation during the tool design process to ensure that your new tooling project becomes a success.

#### Mastip Head Office New Zealand

550 Rosebank Road Avondale, Auckland, New Zealand PO Box 90651, Victoria Street West, Auckland 1142, New Zealand Phone: +64 9 970 2100 Fax: +64 9 970 2070

Email: mastip@mastip.com

#### Mastip Regional Office Europe

Phone: +33 4 724 72 800 Fax: +33 4 724 72 801 Email: europe@mastip.com

#### Mastip Regional Office China

Phone: +86 21 644 77838 Fax: +86 21 644 77828 Email: china@mastip.com

# Mastip Regional Office North America

Phone: +1 262 644 9400 Fax: +1 262 644 9402

Email: northamerica@mastip.com